Riso Comcolor Series

Getting Started Guide No. 4

Using Scanner Mode

Scan to Email
Scan to Hard Drive
Scan to USB Drive
Scan to Shared Folders



Riso (UK) Limited
Scanner Mode V. 2

Please Note

This publication is intended as a brief introduction to the Scanner Mode functions of the Riso Comcolor printer.


In order to use many of the features shown mail destinations and data directories will need to have been previously configured - if in doubt refer to your Comcolor administrator

For full instructions please refer to the user guides supplied with the Riso machine.

Contents


- 2). Scanning Images to Email
- 3). Scanning jobs to a Computer
- 4). Scanning Images to a USB Flash Drive
- 5). Scanning Jobs to Internal Hard Disk

Scanning Images to Email



- Load the originals in the ADF or on the glass platen of the Comcolor scanner:
- 1) On the Operational Panel select > Scanner






- [Confirm] panel will appear: В
- 1). For email select > Format for PC
- 2). Select file format required: > PDF
 - > TIFF

 - > JPEG
- 3). Select > OK



- The [Scanner Mode] panel will now appear:
- 1). Select > Directory

At this stage various adjustment can be made to the file (including naming the file) prior to scanning - please see user guides for full detailS




- The [Directory] panel will now appear: D
- 1). Select > Mail to
- 2). Enter email address of recipient
- or choose recipient from address book (if entered)
- 3). Press > OK

Scanning Jobs to a Computer



- Load the originals in the ADF or on the glass platen of the Comcolor scanner:
- 1) On the Operational Panel select > Scanner





- [Confirm] panel will appear: В
- 1). For email select > Format for PC




- > PDF
- > TIFF
- > JPEG
- 3). Select > OK



- The [Scanner Mode] panel will now appear:
- 1). Select > Directory

At this stage various adjustment can be made to the file (including naming the file) prior to scanning - please see user guides for full details




- The [Directory] panel will now appear: D
- 1). Select > Directory
- 2). Enter destination PC from list


Destination PC names will have previously been configured - if in doubt refer to the Comcolor administrator

3). Press > OK


Scanning Images to a USB Flash Drive



Place a USB Flash Drive in the USB port on the right hand side of the Operational Panel



- Load the originals in the ADF or on the glass platen of the Comcolor scanner:
- 1) On the Operational Panel select > Scanner




- [Confirm] panel will appear:
- 1). For email select > Format for PC
- 2). Select file format required: > PDF / TIFF / JPEG
- 3). Select > OK



- The [Scanner Mode] panel will now appear:
- 1). Select > Directory

At this stage various adjustment can be made to the file (including naming the file) prior to scanning - please see user guides for full details




- The [Directory] panel will now appear:
- 1). Select > Directory
- 2). Select > Scan to USB Flash Drive
- 3). Press > OK


Scanning Jobs to Internal Hard Disk



- Load the originals in the ADF or on the glass platen of the Comcolor scanner:
- 1) On the Operational Panel select > Scanner



- B [Confirm] panel will appear:
- 1). For email select > Format for PC
- 2). Select file format required: > PDF / TIFF / JPEG
- 3). Select > OK



- The [Scanner Mode] panel will now appear:
- 1). Select > Directory

At this stage various adjustment can be made to the file (including naming the file) prior to scanning - please see user guides for full details



- The [Directory] panel will now appear:
- 1). Select > Internal HDD
- 2). Press > OK

For instructions on how to access jobs stored on the Internal Hard Disk from a computer please refer to the Comcolor user guides.